


PRODUCT:	Dahua IVS (Tripwire/Intrusion)
ITEM CODE:	


Introduction

This guide has been formulated to assist with setting up IVS on a Dahua recorder.


1. Right click, select Main Menu



2. Login using credentials




3. Select AI




PureTech Electrical Products Ltd. Telephone: +44 (0)2392 488300	Page 1 of 4 Issued By: Technical Dept
Approved By: Technical Manager	Date: 14/02/2024


4. Select IVS




5. Select the chosen channel and select AI by Camera, then click Add at the bottom right.



6. The following row will appear.



Choose a desired IVS from the drop down menu






(a tripwire is a single line, an Area Intrusion is a complete area)

7. Click draw

1	Enable	Name	Type	Draw	Trigger	Delete
1	<input checked="" type="checkbox"/>	Rule1	Tripwire			

8. Here you can name the rule, set the trigger direction and whether to detect human and or vehicle

 Tripwire

Name


Direction

Target Filter




Effective Ta... Human

Motor Vehicle

9. Using the left mouse button start drawing the line and then the right mouse button to complete the line. The rule name and arrow will show once drawn. When finished click ok



10. Click trigger

1	Enable	Name	Type	Draw	Trigger	Delete
1	<input checked="" type="checkbox"/>	Rule1	Tripwire			

11.

Here you can:

- Schedule the event
- Send an email once triggered
- Set a link to a PTZ camera
- Set camera to sound audio once motion triggered
- Set camera to flash light once motion triggered.

Click Apply once set.

PureTech Electrical Products Ltd. Telephone: +44 (0)2392 488300	Page 4 of 4 Issued By: Technical Dept
Approved By: Technical Manager	Date: 14/02/2024