




Viper Playback and Backup




1 Right click live view and login to recorder



2 Select Start Menu bottom left then Playback




3 At top right, choose date and time of footage.




4 Choose type of recording:

General, Alarm, Intelligent, Motion, POS, Schedule




5 The columns represent the camera channels

Any colours with colour (i.e. blue) show recording on that channel.



6

Click anywhere on the timeline, the playback bar will automatically jump to that point and playback will play.



Backup


7

Format a 64Gb or less USB stick.

[Click here, how to format USB](#)

8


Within playback screen, using left mouse button, select a chunk of the desired playback.




9

Click the backup icon bottom right.

Select "Backup"




10 Confirm the start, end time then press backup.




11 USB stick will show in Device Name.

Change Format to either AVI or MP4

Press Backup



12 Select a password for the footage (If required)



13 Backup will commence

