	Quick Reference Guide
PURE**TECH** TOMORROW'S TECHNOLOGY TODAY	Ref: QRGC004

| **PRODUCT:**	**Cortex VMS**
ITEM CODE:	

Introduction

This guide has been formulated to assist with the initial setup of Cortex VMS.

1. Download and install Cortex VMS from:
   https://support.qvis.co.uk/hc/en-us/articles/360011265158-PC-Software-%CE%BB-Cortex-

2. Select "Add NVR" from top menu bar

   File   Edit   View   Tools   Help

   Add NVR | Remove NVR | Show Selected | Show All | Sequence | Sequence All | Playback Tool | NVR Settings | Alarms

3. Complete the fields with required information:
   (Note: add NVR on same LAN IP address or remotely if port forwarded using port 50000)

   Add NVR - Enter Device Infor...   ?   X

   IP Address:
   Port Number: 50000
   User Name: admin
   Password:
   Device Name:

                        OK   Cancel

4. The NVR will appear in the devices list on top left (press the dropdown to view connected cameras)

   Devices
   ∨ ▬▬▬ 192.168.1.80
              IPCam 1.65
              IPCam 1.66
              IPCam 1.67
              IPCam 1.68

5. Once added you can use menu bar as follows:

| Show chosen cameras | Show all cameras | Set a manual sequence | Sequence all cameras | View playback | Login to NVR | Setup alarms |

6. To login to NVR, select the NVR on left, and click "NVR Settings"

7. Login using NVR login credentials and brows NVR menus as normal.