



PRODUCT:	Viper Recorder Bandwidth
ITEM CODE:	

Introduction

This guide has been formulated to assist with adjusting bandwidth in a Viper NVR.

When adding multiple IP cameras to NVR and the bandwidth is exceeded (preventing you from adding more)

1. Login to NVR, select Settings > Recording, Schedule Recording & Event Recording, both bitrates need to be lowered. (lower to 2048Kbps on each camera).



PureTech Electrical Products Ltd. Telephone: +44 (0)2392 488300	Page 1 of 1 Issued By: Technical Dept
Approved By: Technical Manager	Date: 14/03/2024